

BRB900 GPS Telemetry System

May 10, 2011

Version 0.05



1. Overview:

The BRB900 Telemetry System consists of a GPS receiver and RF transmitter paired with a matching RF receiver. The GPS/Transmitter is placed in the object to be tracked, and the receiver is located at the base station. The GPS computes the position of the object being tracked and transmits this information over an RF data link. The receiver decodes the data, which shows, in real time, the precise location of the object being tracked.

2. Quick Start Guide:

All BRB900 transmitters and receivers arrive preconfigured and ready to run OUT OF THE BOX, no configuration necessary. Simply apply power to the transmitter and make sure the GPS module has a clear view of the sky (initial lock times may exceed 15 minutes). Power is turned on/off by installing/removing the small 2-pin jumper to the right of the 3-pin battery connector). The battery connects to the GPS transmitter via the 3-pin blue connector, and should be left connected at all times (except when charging). See section 15 for a description of the different jumpers and headers.

Plug the receiver into the USB port, or turn on the power switch for the LCD version.

For the USB version, you will also have to run some terminal emulation (e.g. Hyperterm) program to view the GPS data stream. Baud rate should be set to 9600-8-N-1.

For those who want to know more about configuring and using your BRB900 GPS devices, read on.

3. Configurations:

3.1 Configuration #1

This basic setup consists of the entry level transmitter and receiver. Data from the GPS receiver is forward onto the wireless link. The matching receiver contains a USB interface, and reports everything it receives from the wireless link. Multiple transmitters can be enabled at the same time, but will only be decoded by the receiver their destination addressess match. If multiple transmitters are configured with the same destination



address, the receiver will echo all received packets. It is not possible to determine which packets were sent from which receiver. The selection and rate of transmitted NMEA sentences from the GPS module are configured using the “Trimble Studio” software.

If many NMEA sentences are enabled for transmit every second, battery life will be at a minimum and bandwidth usage at a maximum since the transmitter will be active for much of the time.

The networking parameters of the receiver are updated with the X-CTU software via the USB port. It is not possible to update the networking parameters on the transmitter unless the module is removed and transferred temporarily into the receiver.

Figure 1
Configuration #1

3.2 Configuration #2

This is the same as the the previous configuration, but uses the enhanced, or “Smart” version of the transmitter. This transmitter contains a microcontroller, G-switch, and non-volatile memory. The G-switch is used to detect the beginning of the flight. This information will be used to stop the data logging when the memory fills. Up to 1200 data points can be stored at a user defined rate for later download to a .kml file viewable in Google Earth.

The microcontroller can also assemble a “summary” packet from the NMEA data which is then sent over the RF link along with the raw NMEA sentences. In addition to the summarized data, the packet contains a unique identifier. If multiple transmitters are configured with the same destination address, the receiver will echo all received packets. The unique identifier in the summary packets can be used to determine the source of the transmitted data. The source of the NMEA data strings, however, can not be determined. Transmission of both the NMEA strings and summary packets can be individually disabled.




Figure 2:
Configuration #2

Battery usage and bandwidth can be minimized by disabling the transmission of raw NMEA data, and configuring the Summary packet to be transmitted intermittently (every 5 seconds, for example).

3.3 Configuration #3

The third configuration is like #1, but adds the enhanced LCD receiver. If the \$GPGGA NMEA sentence is enabled, the Latitude, longitude, altitude HDOP (Horizontal Dilution of Precision) and number of satellites locked will be displayed on the LCD screen. Other NMEA sentences can be enabled as well, using the Trimble software, and all received data will be sent to the USB port.

The networking parameters of the receiver are updated with the X-CTU software via the USB port. It is not possible to update the networking parameters on the transmitter unless the module is removed and transferred temporarily into the transmitter.




Figure 3 Configuration #3

3.4 Configuration #4

The final configuration uses the enhance LCD receiver and Smart transmitter. As in configuration #3, the GPGL sentences can be displayed on the LCD screen. Additionally, the Receiver can be configured to decode and display the summary packets. Sent by the smart transmitter. In addition to the information described in configuration #3, the summary packets contain VDOP (Vertical Dilution of Precision) as well as the unique identifier and the battery voltage of the transmitter. When the Receiver is first powered on, it looks for the first summary packet and remembers the unique identifier. Subsequent summary packets from other transmitters will be ignored. As with the other receivers, all data (NMEA and Summary packets) that match the destination address will be sent to the USB port.

The networking parameters of the receiver are updated with the X-CTU software via the USB port. The networking parameters of the transmitter may be modified using the "BRB900 Communicator".




Figure 4 Configuration #4

4. BRB 900 Transmitter

The base level transmitter consists of a GPS receiver, 900 MHz spread spectrum transmitter, and battery regulator circuitry.

Power is supplied via J4 and J5. The battery is connected via J4 and can be left in indefinitely. While power is applied to J4, the GPS module's battery backup circuit is powered on and keeps the almanac and ephemeris up to date, allowing for quicker lock times. Jumper J5 may be used to turn the rest of the board ON and OFF.

The LED will blink when GPS lock is obtained.

The rate and selection of NMEA sentences are controlled by directly programming the GPS receiver using the *Trimble Studio* program. Access to the GPS receiver is provided via J2 and pictured below: The default setup transmits the \$GPRMC sentence once every 5 seconds.

The RF transmitter cannot be modified while the transmit module is installed in the base level transmitter. It must be removed and installed into one of the receivers

WARNING: Incorrect programming of either the GPS module or radio transmitter can result in broken communication links. Please do not modify the GPS or transmitter parameters without a detailed understanding of the changes you are about to make.

The enhanced version of the transmitter adds a microcontroller and additional circuitry to log flight data. To configure the microcontroller parameters, use the BRB900 programming software. Access to the microcontroller is provided via J1 and pictured below. With the enhanced version, both the gaps and RF parameters are managed by the brb900 configuration software

It is NOT possible to upgrade from the base level to the enhanced version of the BRB900 Transmitter.

5. BRB900 Receiver

The base level receiver consists of a 900 MHz spread spectrum radio module with a USB interface that appears as a virtual serial port. Power is provided via the USB interface, and data is transmitted at 9600 baud, 8 data bits, No parity 1 stop bit (9600-8-N-1). Trimble Studio or many other readily available software packages can be used to display the NMEA data received from the GPS transmitter. The RF transmitter is configured using the X-CTU programming software over the USB link.

The LCD version of the transmitter adds a microcontroller and LCD display. The LCD display is battery powered, and can be charged over the USB port. The RF transmitter is configured using the X-CTU programming software over the USB link.

The LCD receiver can be configured to decode two data packet types sent from the transmitter, \$GPGGA and \$BRBTX. Switching between the modes is accomplished by turning the power on while the configuration button is pressed. The receive mode will be stored in non-volatile memory and reloaded on subsequent power-ups.

It is NOT possible to upgrade from the base level to the enhanced version of the BRB900 Receiver.

6. Transmit Modes

There are three transmit modes:

Raw GPS Data: A jumper connects the output of the GPS module directly to the input of the RF transmitter. On the receive side, the raw NMEA sentences are echoed on the USB Data Port. The user is responsible for enabling and setting the rate of the sentences produced by the GPS module, in the default configuration, the GPS will produce the \$GPGSA and \$GPGGA sentences once every second. Keep in mind that the bandwidth is shared by *all* transmitters using the 900 MHz frequencies allocated to these devices.

This is the only mode available in the entry level BRB900 transmitter.

Echo RAW GPS Data: A jumper connects the output of the GPS module to the onboard microcontroller. The microcontroller echoes all sentences from the GPS module to the RF transmitter, and adds a special sentence that summarizes the GPS data, \$BRBTX. This special packet also contains a unique identifier.

A user selectable firmware option determines whether the RAW NMEA sentences are echoed.

This mode requires the microcontroller enhanced version of the BRB900 transmitter.

\$BRBTX Summary: \$BRBTX sentence is sent over the RF link at a user defined rate. This mode results in the lowest power consumption and minimal use of the RF bandwidth. This is the recommended mode of operation.

A user selectable firmware option determines whether the RAW NMEA sentences are echoed.

7. Receive Modes

The receiver has a USB data port and an optional LCD display.

USB data port: All received data packets are echoed to the USB Data port. This includes the NMEA sentences as well as the special \$BRBTX packet. No interpretation ordering or filtering of packets is performed by the receiver. If multiple transmitters are present (and the routing parameters set so that the receiver does not discard them) the data from all will be echoed on the USB port. In this mode, it is not possible to differentiate between data packets received from two different transmitters.

LCD Display: The receiver will look for \$BRBTX sentence and display the contents of the summary packet on the LCD display. It will remember the unique identifier from the first \$BRBTX sentence received, and ignore any \$BRBTX data from other transmitters. If the \$BRBTX packet is NOT detected, it will attempt to decode the existing packets. It is not possible to differentiate between data packets received from two different transmitters unless the BRBTX packet is present

8. Programming Software

The programming software for the BRB900 TX is pictured below along with a description of the fields.



Com Port: Serial or USB Virtual serial port identifier.

Shutdown Voltage: Default: 3.4 Volts. The BRB900 Transmitter contains battery monitoring circuitry and will shutdown the transmitter if the voltage falls below the programmed level.

Store Interface: Approx 1200 data points can be saved in the on board non-volatile memory. Data is stored every “N” seconds, in this case 1.

Transmit Interval: the \$BRBTX data packet is transmitter every N seconds, in this case, 5.

G_Switch: The BRB900 Transmitter contains an onboard G-switch to mark the beginning of flight when liftoff is detected.

Wrap Mem: Flight data will be continuously logged to memory, wrapping around to the beginning when the end is reached. If this box is not checked, data logging will stop when the end of memory is reached.

Enable NMEA: The raw NMEA sentences from the GPS are echoed onto the RF Data Link.

Enable \$BRBTX: The \$BRBTX sentence is sent on the RF data link every “N” seconds as indicated by the Transmit Interval

Read: Read the device parameters. Make sure to select the proper COM port. Always being a programming session with a Read command

Write: Write the device parameters

Read Flash: Read the contents of the flight data logged in non-volatile memory.

Clear Flash: Clear the non-volatile memory. It is recommended to clear the memory before e each flight.

Go: Exit command mode.

9. Networking Parameters

In addition to the unique identifier contained in the \$BRBTX sentence, the transmitter and receiver use several identification parameters that determine which RF packets will be decoded by the receiver. These include a Vendor ID, Hopping Channel, and Destination address. By default, each receiver is programmed to recognize up to 4 different destination addresses. Each transmitter must have a matching Vendor ID, Hopping Channel and group of destination addresses.

It is possible to modify the networking parameters of the RF transmitter. This functionality is enabled by invoking the BRB900 Communicator with the “-rf” command line option.

These parameters can be modified so that all packets matching the Vendor ID and Hopping Channel are displayed. Additionally the Vendor ID and Hopping Channel can be modified to match other vendors.

Default Settings for Address Parameters:


Hopping Channel (ATHP): The default hopping channel for the BRB900 transmitter and receiver is 5, and should not be changed.


Address Mask (ATMK): The default address mask is 0xFFFF and should not be changed.

Destination Address (ATDT): Each transmit/receive pair is shipped with a unique/matching destination address. In order for the Receiver to decode the transmitter packets, the Destination addresses must match. If you purchase additional transmitters, you can change the Destination Address to match your existing receiver.

Vendor Identification (ATID): The default Vendor ID is 0x3BEE, and should not be changed.

UPDATE: The update button will modify the BRB900 Transmitter parameters. Use extreme caution when modifying these parameters.





	GPS Parameters	RF Parameters
Base Transmitter	Trimble Software	N/A *
Enhanced Transmitter	Trimble Software	BRB900 Communicator
Base Receiver		X-CTU Software
Enhanced (LCD) Receiver		X-CTU Software

*The RF parameters cannot be modified while the transmitters is installed in the base level transmitter

10. Special Sentence Format

\$BRBTX

BigRedBee Summary Information


\$BRBTX, ID0001, *, 033618, 3412.3456N, 12345.6789W, 04, 2.69, 012345, 1.24, 2F0

Where:


\$BRBTX	BigRedBee Summary Packet
ID0001	Unique identifier string
*	BRB Status Flag
033618	fix taken at 033618 UTC Time
3412.3456N	Latitude 34 degrees 12.3456 minutes North
12345.6789W	Longitude 123 degrees 45.6789W minutes West
04	4 satellites user to compute position
2.69	HDOP
012345	Altitude in Meters or Feet
1.24	VDOP
2F0	Raw A/D conversion of onboard battery voltage

11. LCD Display


When the power switch is turned on, the LCD will display the following information: The firmware version (V0.01) and the battery voltage of the receiver are displayed. The BRB-LCD can be configured to display the information from the \$GPGGA sentence, or the \$BRBTX sentence. Switching between modes is accomplished by holding the configuration button while the unit is powered on.




If the configuration button is held when power is applied, the NMEA mode will be toggled.




The 16x3 line LCD display contains the following information when decoding the \$GPGGA NMEA sentence




The 16x3 line LCD display contains the following information when decoding the \$BRBTX Summary sentence before the GPS has locked. Note that the battery voltage and # of satellites are valid.



The 16x3 line LCD display contains the following information when decoding the \$BRBTX Summary sentence.



Altitude in this mode is “MSL”. If the configuration button is held, the LCD receiver will “lock in” the currently altitude as the “base” altitude, and report all future altitudes as “AGL”. Negative altitudes will be displayed as “0”.



*	Status Character: ‘*’
4535.567	Latitude: 45° 34.5678”
12234.5678	Longitude: 122° 34.5678”
12345	Altitude: 12345
H269	Horizontal Dilution of Precision (HDOP): 2.69
V909	Vertical Dilution of Precision (VDOP) 9.09
23	Time of Day (Seconds only): 23
S4	Number of satellites in view: 4
B395	Voltage of Battery on Transmitter 3.95V

12. BigRedBee USB Interface and Charger

The BigRedBee USB interface integrates the functionality of two separate devices; a USB data interface, and a single cell lithium poly battery charger. The charger and programming interface functions should not be used at the same time. When programming the device, the battery must be used to provide power. Power is NOT provided via the USB interface. Do not attempt to charge the battery and modify the device parameters at the same time.



12.1 Single Cell Lithium Poly Charger

Plug the USB cable into the USB interface board and connect to your computer’s USB port. Plug the battery into the three pin connector. The LED will remain on while the battery is charging, and turn off once it is fully charged. Charge rate is 100 milliamps per hour.

The battery charger function is independent of the data interface. The battery WILL NOT CHARGE unless it is connected directly to the 3-pin header on the USB / charger interface.

12.2 USB Data Interface

Apply power to the transmitter. Plug the USB cable into the USB interface board and connect to your computer's USB port.. If this is the first time you have used this type of USB interface, Windows will need to install the drivers for it.


Once Windows has recognized the device, plug the 5-pin connector on the USB adapter into the Beeline transmitter. Now you can use the BeeLine Communicator to modify the device parameters. Make sure to select the proper COM port

Drivers are located here: <http://www.ftdichip.com/FTDrivers.htm>


13. Trimble Studio:

The default configuration should work for most users, but here's a summary of the steps needed to modify the parameters of the GPS Module. Be careful not to touch the PORT configurations, as it can easily get you into a position where you're unable to communicate with the device. You should only have to make these modifications once, as they parameters are stored in non-volatile memory inside the GPS module.


Executing Trimble studio brings up the start screen that looks like this:



Clicking on "New connection" will bring up the Port settings.




In this case, we've selected COM 3, and 9600-8-E-1. Click on OK




Next we see the main status screen – notice the “satellite data” section is populated with data, and that the RX light is blinking


Selecting Receiver->Configure and then select the NMEA configuration tab.



If you are using the base level transmitter, enable the sentences you desire and the Output Interval. If you are using the LCD enhanced receiver, you should make that at least the GGA sentence is enabled. If using the Summary mode on an enhanced transmitter, then set the output Interval to 1, and make sure that GSA is enabled along with GGA. Make sure to "Set" and "Save Configuration".



The GPS configuration should be left unchanged



And the position filters should be disabled.

14. Misc Info

14.1 RECEIVER

14.2 TRANSMITTER

Transmitter Dimensions: 1.25" wide x 2.85" long, excluding transmit antenna.

Antenna: Reverse Polarity SMA, 3dbi gain approx 4.25" long

GPS Module: 12 Channels Trimble Lassen IQ with integrated ceramic patch antenna. Altitude and speed may exceed 18,000 meters or 515 meters/second, but not both.

RF Transmitter: 100 mw 900 Mhz Spread Spectrum.

Receive Current : 115mA

Transmit Current: 315mA

Power supply: Single cell Lithium Poly battery (3.5 to 4.2 Volts)

15. Board Description


15.1 Board Orientation

If your board contains a G-switch, then the board must be installed vertically with the RF antenna point up. Failure to do so may result in a failure of the G-switch to detect launch.

15.2 Battery Description

1) Plug battery J5 into board J4, this may be left plugged in indefinitely, and provide backup battery power to the almanac and ephemeris data log in the GPS device reducing future lock times.

2) Install jumper in J3, connecting the two pins. This can be used to turn power on and off.



Programming:

Plug J7 into J1, aligning pin 1

15.3 GPS Programming

Plug J7 into J2, aligning pin 1.

15.4 Battery Charging

Plug J5 into J6, and the usb connector into the PC. The connectors are keyed, and can only be installed in one direction.